


PIN Codes for HP LaserJet Service Menu

Newer HP printer models require the entering of a PIN code to access the Service Menu. PIN codes can be found in the service manuals, however here is a handy list for quick reference.

Note: The Service Menu is intended for repair technicians and generally includes options like clearing the event log, changing the maintenance count, maintenance interval, etc.



HP Printer Model	Service Menu PIN Code
LaserJet 2300	11230002
LaserJet 2410	10241004
LaserJet 2420	10242004
LaserJet 2430	10243004
Color LaserJet 3000	11300005
Color LaserJet 3500	10350003
Color LaserJet 3550	10350003
Color LaserJet 3600	11360005
Color LaserJet 3700	10370003
Color LaserJet 3800	11380005
LaserJet 4100 MFP	04410002
LaserJet 4101 MFP	04410002
LaserJet 4200	11420002
LaserJet 4240	04424005
LaserJet 4250	09425004
LaserJet 4300	11430002
LaserJet 4345 MFP	11434504
LaserJet 4350	09435004
Color LaserJet 4600	04460002
Color LaserJet 4610	05465004
Color LaserJet 4650	05465004
Color LaserJet 4700	09470005
Color LaserJet 4730 MFP	09473005
LaserJet 5200	05520006
Color LaserJet 5500	04550002
Color LaserJet 5550	09555004

LaserJet 9000	00900001
LaserJet 9040	04904005
LaserJet 9050	09905004
LaserJet 9500	04950003
LaserJet 9000 MFP	00900001
LaserJet 9040 MFP	11904004
LaserJet 9050 MFP	09905004
Color LaserJet 9500 MFP	04950003
LaserJet cp4005	10400506
Color laserjet CP3505	06350507
Color laserjet CP4005	10400506
Color laserjet CP6015	03601508
LaserJet M3027	11303506
LaserJet M3035	11303506
LaserJet M4345	11434506
LaserJet M5025	11503506
LaserJet M5035	11503506
LaserJet P3005	10300506
LaserJet P4014	05401408
LaserJet P4015	05401508
LaserJet P4515	05451508